

Fanless Box-PC 50 / 50W

PKBX5452

PKBX5453

User Manual

Published July 2016

CONTENTS

Preface

Copyright	iv
Disclaimer	iv
Acknowledgements	iv
Regulatory Compliance Statements	iv
Declaration of Conformity	iv
RoHS Compliance	v
Warranty and RMA	vi
Safety Information	viii
Installation Recommendations	viii
Safety Precautions	ix
Technical Support and Assistance	x
Conventions Used in this Manual	x
Package Contents	xi
Ordering Information	xii

Chapter 1: Product Introduction

Overview	1
Key Features	1
Fanless Box-PC 50	1
Fanless Box-PC 50W	1
Hardware Specifications	2
Knowing Your Fanless Box-PC 50 / 50W	4
Front Panel	4

Rear Panel	5
Mechanical Dimensions	6
Fanless Box-PC 50	6
Fanless Box-PC 50W	7

Chapter 2: Jumpers and Connectors

Before You Begin	8
Precautions	8
Jumper Settings	9
Locations of the Jumpers and Connectors for NISB 50	10
NISB 50	10
Jumpers	11
AT/ATX Power Select	11
CMOS Clear Select	11
ME Clear Select	12
COM3 RS422/485 Select	12
SIM Card Power Select	13
COM1 5V/12V/RI Select	13
COM3 TX Terminal Pin header	14
COM3 RX Terminal Pin header	14
Connector Pin Definitions	15
External I/O Interfaces - Front Panel	15
Power Button	15
SIM Card Slot	15
HDMI	16
USB1/2 Ports (USB 2.0)	16

USB3/4 Ports (USB 2.0).....	17
LAN 1 Port	17
LAN 2 Port	18
External I/O Interfaces - Rear Panel.....	19
24V DC Power Input	19
COM 1 Port (RS232).....	19
COM 2 Port (RS232).....	20
COM 3 Port (RS422/485 Only).....	20
Line-out Connector	21
Internal Connectors.....	22
LAN1 LED Signal Pin Header.....	22
LAN2 LED Signal Pin Header.....	22
SATA Connector.....	23
SATA Power Connector	23
GPIO Pin Header	24
Mic-in Pin Header.....	24
COM 4 Pin Header (RS232)	25
Power & HDD LEDs/Power & Reset Switches.....	25
RTC Connector	26
SMBUS Pin Header	26
SPI and I2C Pin Header.....	27
GPIO Pin Header	27
UART Pin Header (Signal from CPU)	28
Mini-PCle Connector (3G/4G/mSATA).....	29
Mini-PCle Connector (3G/4G/Wi-Fi).....	30
Half-size Mini-PCle Connector (Wi-Fi).....	31

Chapter 3: System Setup

Removing the Chassis Cover	32
Installing a Wi-Fi/BT Mini-PCle Module (Half-size).....	33
Installing a Mini-PCle Module (Full-size).....	34
Installing a 3G Mini-PCle Module (Half-size).....	35

Installing a SIM Card	36
Installing an Antenna	38
Installing a 2.5" SSD/HDD Storage (for PKBX5453 Only)	40
Wallmount Installation	43
DIN Rail Clip Installation	44
Aluminum DIN Rail Clip Installation	45
Packing PKBX5452	46
Packing PKBX5453	48

Chapter 4: BIOS Setup

About BIOS Setup	50
When to Configure the BIOS.....	50
Default Configuration.....	51
Entering Setup	51
Legends	51
BIOS Setup Utility.....	53
Main	53
Advanced	54
Chipset.....	64
Security	66
Boot.....	67
Save & Exit	68

Appendix A: Power Consumption69

Appendix B: GPIO Control Commands

Command List.....	70
GPIO Default Table.....	70
Read GPIO Status Sequence	71
Write GPIO Status Sequence	71
Read GPIO Direction Sequence.....	72
Write GPIO Direction Sequence	72

PREFACE

Copyright

This publication, including all photographs, illustrations and software, is protected under international copyright laws, with all rights reserved. No part of this manual may be reproduced, copied, translated or transmitted in any form or by any means without the prior written consent from DELTA COMPONENTS GmbH.

Disclaimer

The information in this document is subject to change without prior notice and does not represent commitment from DELTA COMPONENTS GmbH. However, users may update their knowledge of any product in use by constantly checking its manual posted on our website: <http://www.delta-components.com>. DELTA COMPONENTS shall not be liable for direct, indirect, special, incidental, or consequential damages arising out of the use of any product, nor for any infringements upon the rights of third parties, which may result from such use. Any implied warranties of merchantability or fitness for any particular purpose is also disclaimed.

Acknowledgements

Fanless Box-PC 3700E/E2/P2/P2E are trademarks of DELTA COMPONENTS GmbH. All other product names mentioned herein are registered trademarks of their respective owners.

Regulatory Compliance Statements

This section provides the FCC compliance statement for Class A devices and describes how to keep the system CE compliant.

Declaration of Conformity

FCC

This equipment has been tested and verified to comply with the limits for a Class A digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. Operation of this equipment in a residential area (domestic environment) is likely to cause harmful interference, in which case the user will be required to correct the interference (take adequate measures) at their own expense.

CE

The product(s) described in this manual complies with all applicable European Union (CE) directives if it has a CE marking. For computer systems to remain CE compliant, only CE-compliant parts may be used. Maintaining CE compliance also requires proper cable and cabling techniques.

RoHS Compliance



DELTA COMPONENTS RoHS Environmental Policy and Status Update

DELTA COMPONENTS is a global citizen for building the digital infrastructure. We are committed to providing green products and services, which are compliant with

European Union RoHS (Restriction on Use of Hazardous Substance in Electronic Equipment) directive 2011/65/EU, to be your trusted green partner and to protect our environment.

RoHS restricts the use of Lead (Pb) < 0.1% or 1,000ppm, Mercury (Hg) < 0.1% or 1,000ppm, Cadmium (Cd) < 0.01% or 100ppm, Hexavalent Chromium (Cr6+) < 0.1% or 1,000ppm, Polybrominated biphenyls (PBB) < 0.1% or 1,000ppm, and Polybrominated diphenyl Ethers (PBDE) < 0.1% or 1,000ppm.

In order to meet the RoHS compliant directives, DELTA COMPONENTS has established an engineering and manufacturing task force to implement the introduction of green products. The task force will ensure that we follow the standard DELTA COMPONENTS development procedure and that all the new RoHS components and new manufacturing processes maintain the highest industry quality levels for which DELTA COMPONENTS are renowned.

The model selection criteria will be based on market demand. Vendors and suppliers will ensure that all designed components will be RoHS compliant.

How to recognize DELTA COMPONENTS RoHS Products?

For existing products where there are non-RoHS and RoHS versions, the suffix (LF) will be added to the compliant product name.

All new product models launched after January 2013 will be RoHS compliant. They will use the usual DELTA COMPONENTS naming convention.

Warranty and RMA

DELTA COMPONENTS GmbH Warranty Period

DELTA COMPONENTS manufactures products that are new or equivalent to new in accordance with industry standard. DELTA COMPONENTS warrants that products will be free from defect in material and workmanship for 2 years, beginning on the date of invoice by DELTA COMPONENTS. HCP series products (Blade Server) which are manufactured by DELTA COMPONENTS are covered by a three year warranty period.

DELTA COMPONENTS Return Merchandise Authorization (RMA)

- Customers shall enclose the DELTA COMPONENTS RMA Service Form with the returned packages.
- Customers must collect all the information about the problems encountered and note anything abnormal or, print out any on-screen messages, and describe the problems on the DELTA COMPONENTS RMA Service Form for the RMA number apply process.
- Customers can send back the faulty products with or without accessories (manuals, cable, etc.) and any components from the card, such as CPU and RAM. If the components were suspected as part of the problems, please note clearly which components are included. Otherwise, DELTA COMPONENTS is not responsible for the devices/parts.
- Customers are responsible for the safe packaging of defective products, making sure it is durable enough to be resistant against further damage and deterioration during transportation. In case of damages occurred during transportation, the repair is treated as Out of Warranty.
- Any products returned by DELTA COMPONENTS to other locations besides the customers site will bear an extra charge and will be billed to the customer.

Repair Service Charges for Out-of-Warranty Products

NDELTA COMPONENTS will charge for out-of-warranty products in two categories, one is basic diagnostic fee and another is component (product) fee.

Repair Service Charges for Out-of-Warranty Products

DELTA COMPONENTS will charge for out-of-warranty products in two categories, one is basic diagnostic fee and another is component (product) fee.

System Level

- Component fee: DELTA COMPONENTS will only charge for main components such as SMD chip, BGA chip, etc. Passive components will be repaired for free, ex: resistor, capacitor.
- Items will be replaced with DELTA COMPONENTS products if the original one cannot be repaired. Ex: motherboard, power supply, etc.
- Replace with 3rd party products if needed.
- If RMA goods can not be repaired, DELTA COMPONENTS will return it to the customer without any charge.

Board Level

- Component fee: DELTA COMPONENTS will only charge for main components, such as SMD chip, BGA chip, etc. Passive components will be repaired for free, ex: resistors, capacitors.
- If RMA goods can not be repaired, DELTA COMPONENTS will return it to the customer without any charge.

Warnings

Read and adhere to all warnings, cautions, and notices in this guide and the documentation supplied with the chassis, power supply, and accessory modules. If the instructions for the chassis and power supply are inconsistent with these instructions or the instructions for accessory modules, contact the supplier to find out how you can ensure that your computer meets safety and regulatory requirements.

Cautions

Electrostatic discharge (ESD) can damage system components. Do the described procedures only at an ESD workstation. If no such station is available, you can provide some ESD protection by wearing an antistatic wrist strap and attaching it to a metal part of the computer chassis.

Installation Recommendations

Ensure you have a stable, clean working environment. Dust and dirt can get into components and cause a malfunction. Use containers to keep small components separated.

Adequate lighting and proper tools can prevent you from accidentally damaging the internal components. Most of the procedures that follow require only a few simple tools, including the following:

- A Philips screwdriver
- A flat-tipped screwdriver
- A grounding strap
- An anti-static pad

Using your fingers can disconnect most of the connections. It is recommended that you do not use needle-nose pliers to disconnect connections as these can damage the soft metal or plastic parts of the connectors.

Safety Information

Before installing and using the device, note the following precautions:

- Read all instructions carefully.
- Do not place the unit on an unstable surface, cart, or stand.
- Follow all warnings and cautions in this manual.
- When replacing parts, ensure that your service technician uses parts specified by the manufacturer.
- Avoid using the system near water, in direct sunlight, or near a heating device.
- The load of the system unit does not solely rely for support from the rackmounts located on the sides. Firm support from the bottom is highly necessary in order to provide balance stability.
- The computer is provided with a battery-powered real-time clock circuit. There is a danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Discard used batteries according to the manufacturer's instructions.



Danger of explosion if battery is incorrectly replaced. Replace with the same or equivalent type recommended by the manufacturer. Discard used batteries according to the manufacturer's instructions.



ATTENTION
IL Y A RISQUE D'EXPLOSION SI LA BATTERIE EST REMPLACÉE
PAR UNE BATTERIE DE TYPE INCORRECT.
METTRE AU REBUT LES BATTERIES USAGÉES
CONFORMÉMENT AUX INSTRUCTIONS.



This product is intended to be supplied by a Listed Power Adapter, rated 24Vdc, 5A minimum, Tma = 55 degrees C, and the altitude of operation = 2000m. (2000m for general requirement, 5000m for collocation with Adapter: FSP Group Inc. / FSP060-DAAN2.)
If need further assistance with purchasing the power source, please contact to DELTA COMPONENTS for further information.

Safety Precautions

1. Read these safety instructions carefully.
2. Keep this User Manual for later reference.
3. Disconnect this equipment from any AC outlet before cleaning. Use a damp cloth. Do not use liquid or spray detergents for cleaning.
4. For plug-in equipment, the power outlet socket must be located near the equipment and must be easily accessible.
5. Keep this equipment away from humidity.
6. Put this equipment on a stable surface during installation. Dropping it or letting it fall may cause damage.
7. The openings on the enclosure are for air convection to protect the equipment from overheating. DO NOT COVER THE OPENINGS.
8. Make sure the voltage of the power source is correct before connecting the equipment to the power outlet.
9. Place the power cord in a way so that people will not step on it. Do not place anything on top of the power cord. Use a power cord that has been approved for use with the product and that it matches the voltage and current marked on the product's electrical range label. The voltage and current rating of the cord must be greater than the voltage and current rating marked on the product.
10. All cautions and warnings on the equipment should be noted.
11. If the equipment is not used for a long time, disconnect it from the power source to avoid damage by transient overvoltage.
12. Never pour any liquid into an opening. This may cause fire or electrical shock.
13. Never open the equipment. For safety reasons, the equipment should be opened only by qualified service personnel.
14. If one of the following situations arises, get the equipment checked by service personnel:
 - a. The power cord or plug is damaged.
 - b. Liquid has penetrated into the equipment.
 - c. The equipment has been exposed to moisture.
 - d. The equipment does not work well, or you cannot get it to work according to the user's manual.
 - e. The equipment has been dropped and damaged.
 - f. The equipment has obvious signs of breakage.
15. Do not place heavy objects on the equipment.
16. The unit uses a three-wire ground cable which is equipped with a third pin to ground the unit and prevent electric shock. Do not defeat the purpose of this pin. If your outlet does not support this kind of plug, contact your electrician to replace your obsolete outlet.
17. CAUTION: DANGER OF EXPLOSION IF BATTERY IS INCORRECTLY REPLACED. REPLACE ONLY WITH THE SAME OR EQUIVALENT TYPE RECOMMENDED BY THE MANUFACTURER. DISCARD USED BATTERIES ACCORDING TO THE MANUFACTURER'S INSTRUCTIONS.

Technical Support and Assistance

1. For the most updated information of DELTA COMPONENTS products, visit DELTA COMPONENTS website at www.delta-components.de
2. For technical issues that require contacting our technical support team or sales representative, please have the following information ready before calling:
 - Product name and serial number
 - Detailed information of the peripheral devices
 - Detailed information of the installed software (operating system, version, application software, etc.)
 - A complete description of the problem
 - The exact wordings of the error messages

Warning!

1. Handling the unit: carry the unit with both hands and handle it with care.
2. Maintenance: to keep the unit clean, use only approved cleaning products or clean with a dry cloth.

Conventions Used in this Manual



Warning:

Information about certain situations, which if not observed, can cause personal injury. This will prevent injury to yourself when performing a task.



Caution:

Information to avoid damaging components or losing data.



Note:

Provides additional information to complete a task easily.

Package Contents

Before continuing, verify that the package that you received is complete. Your Fanless Box-PC 50 / 50W package should have all the items listed in the following tables.

Fanless Box-PC 50

Item	Part Number	Description	Qty
1		PE Zipper Bag #8 170x240mm	1
2		Quick Reference Guide VER: A Size: A4	1
3		PE Zipper Bag #3 100x70mm	2
4		Round Head Screw P2x3 NI Nylok	6
5		Terminal Blocks 3P Male DIP Green	1
6		Mini PCIe Bracket 29x30x2.1mm SPCC t= 1.0mm NI	1
7		Flat Head Screw F2x4 NIGP Nylok	2
8		DVD Driver VER: 1.0	1

Fanless Box-PC 50W

Item	Part Number	Description	Qty
1		PE Zipper Bag #8 170x240mm	1
2		Quick Reference Guide VER:A SIZE:A4	1
3		PE Zipper Bag #3 100x70mm	2
4		Round Head Screw P2x3 NI NYLOK	6
5		Terminal Blocks 3P Male DIP Green	1
6		Mini PCIe Bracket 29x30x2.1mm SPCC t=1.0mm NI	1
7		Flat Head Screw F2x4 NIGP Nylok	2
8		DVD Driver VER: 1.0	1
9		Chain Bag #6 170x120mm	1
10		PCB For HDD Tray 100x94mm Thickness:1.6mm	1
11		I Head Screw: M3x4mm	8

Ordering Information

The following information below provides ordering information

- **Barebone**

Fanless Box-PC 50 (PKBX5452)

- Intel® Atom™ processor E3826 dual core fanless system, with onboard 16GB EMMC and 2GB DDR3L RAM

Fanless Box-PC 50W (PKBX5453)

- Intel® Atom™ processor E3826 dual core fanless system, with onboard 16GB EMMC and 2G DDR3L RAM

- **24V, 60W AC/DC power adapter w/o power cord (NASX5238)**

CHAPTER 1: PRODUCT INTRODUCTION

Overview



Fanless Box-PC 50



Fanless Box-PC 50W

Key Features

- Onboard Intel® Atom™ processor E3826 dual core, 1.46GHz
- 1x HDMI display
- 2x Intel® I120AT GbE LAN ports; support WoL, Teaming and PXE
- 4x USB 2.0
- 3x mini-PCIe sockets for optional Wi-Fi/3.5G/LTE modules
- 1x RS232, 1x RS232 (only Tx/Rx/GND), 1x RS422/485 with auto flow control
- Support -5 ~ 55 degree C operating temperature
- Support 24V DC input
- 1x 2.5" Front Accessible HDD Tray

Hardware Specifications

CPU Support

- Default: Onboard Intel® Atom™ processor E3826 Dual Core, 1.46GHz
- Optional: Support Intel® Atom™ processor E3845 Quad Core, 1.91GHz (by request)

Main Memory

- Onboard 2GB DDR3L 1066/1333 RAM
 - Un-buffered and non-ECC
 - Max up to 4GB for option

Display Option

- 1x HDMI display

I/O Interface - Front

- ATX power on/off switch
- 1x Storage/2x GPO programmable LED
- 1x SIM card holder
- 2x Intel® I210AT GbE LAN ports; support WoL, Teaming and PXE
- 1x HDMI Display Output
- 4x USB 2.0 (500mA per each)
- 2x Antenna holes for optional Wi-Fi/3.5G antenna

I/O Interface - Rear

- 3x DB9 for COM1 & COM2 & COM3
 - COM1: Full RS232 signal
 - COM2: RS232, only supports Tx/Rx/GND
 - COM3: RS422/485 auto flow control
- 1x Line-out
- Support 24V DC INPUT

I/O Interface - Internal

- 4x GPI and 4x GPO (Programmable to GPI or GPO)
- 1x DB9, only supports RS232, Tx/Rx/GND single

Storage Device

- Onboard 16GB EMMC
- Optional mSATA module
- Optional 2.5" HDD/SSD in 7mm thickness (PKBX5453 only)

Expansion Slot

- 3x Mini-PCIe sockets for optional Wi-Fi/3.5G modules

Mini-PCIe	Size	USB	PCIe	mSATA	3.5G/4G
CN5	Full	✓	N/A	Support	Support
CN6	Full	✓	✓	N/A	Support
CN7	Half	✓	✓	N/A	N/A

Power Requirements

- Power input: 24V DC +/-20%
- 1x optional 24V, 60W power adapter

Support OS

Model Name		F. Box-PC 50		F. Box-PC 50-4G-32G		Box-PC 50W
Storage		eMMC 16GB	mSATA	eMMC 32GB	mSATA	SSD
Memory		2GB		4GB		2GB
OS	Android 4.4	64-bit		64-bit		
	Windows 10 IoT Enterprise			64-bit	64-bit	
	WES8	32-bit	32-bit	64-bit	64-bit	32-bit
	Windows 7 Professional		32-bit		64-bit	32-bit
	WES7E		32-bit		64-bit	32-bit
	WEC7		32-bit		32-bit	32-bit

* Note: Only one LAN can be active under Android 4.4.

Dimensions

- Fanless Box-PC 50: 162mm(W) x 26mm(H) x 150mm(D) without wall-mount bracket
- Fanless Box-PC 50W: 261mm(W) x 26mm(H) x 150mm(D) without wall-mount bracket

Construction

- Metal chassis with fanless design

Environment

- Operating Temperature:
Ambient with air flow: -5°C to 55°C
(According to IEC60068-2-1, IEC60068-2-2, IEC60068-2-14)
- Storage Temperature: -20°C to 75°C
- Relative Humidity: 10% to 95% (non-condensing)

Fanless Box-PC 50:

- Shock Protection:
 - mSATA / EMMC: 50G, half sine, 11ms, IEC60068-27
- Vibration protection w/mSATA or EMMC condition:
 - Random: 2Grms @ 5~500 Hz, IEC60068-2-64
 - Sinusoidal: 2Grms @ 5~500 Hz, IEC60068-2-6

Fanless Box-PC 50W:

- Shock Protection:
 - HDD: 20G, half sine, 11ms, IEC60068-27
 - SSD / mSATA: 50G, half sine, 11ms, IEC60068-27
- Vibration protection w/HDD condition:
 - Random: 0.5Grms @ 5~500 Hz, IEC60068-2-64
 - Sinusoidal: 0.5Grms @ 5~500 Hz, IEC60068-2-6
- Vibration protection w/SSD or mSATA condition:
 - Random: 2Grms @ 5~500 Hz, IEC60068-2-64
 - Sinusoidal: 2Grms @ 5~500 Hz, IEC60068-2-6


Certifications

- CE
- FCC Class A
- UL/cUL

Knowing Your Fanless Box-PC 50 / 50W

Front Panel

Fanless Box-PC 50



HDD/SSD Drive Bay

Used to install a 2.5" HDD/SSD.

Antenna Hole

Used to install external antennas.

Power Switch

Press to power-on or power-off the system.

SIM

Used to insert a SIM card.

LED Indicators

Indicates the hard drive and GPIO (programmable) activity of the system.

HDMI

Used to connect a high-definition display.


USB 2.0

USB 2.0 ports to connect the system with USB 2.0/1.1 devices.

LAN


Used to connect the system to a local area network.

Fanless Box-PC 50W



Rear Panel

Fanless Box-PC 50



DC Input

Used to plug a DC power cord.

COM1 to COM3


Three DB9 ports used to connect serial devices.

- COM1: Full RS232 signal
- COM2: RS232, only supports Tx/Rx/GND
- COM3: RS422/485 auto flow control

Line-out


Used to connect a headphone or a speaker.

Fanless Box-PC 50W




Mechanical Dimensions

Fanless Box-PC 50



Fanless Box-PC 50W



CHAPTER 2: JUMPERS AND CONNECTORS

This chapter describes how to set the jumpers and connectors on the Fanless Box-PC 50 / 50W motherboard.

Before You Begin

- Ensure you have a stable, clean working environment. Dust and dirt can get into components and cause a malfunction. Use containers to keep small components separated.
- Adequate lighting and proper tools can prevent you from accidentally damaging the internal components. Most of the procedures that follow require only a few simple tools, including the following:
 - A Philips screwdriver
 - A flat-tipped screwdriver
 - A set of jewelers screwdrivers
 - A grounding strap
 - An anti-static pad
- Using your fingers can disconnect most of the connections. It is recommended that you do not use needle-nosed pliers to disconnect connections as these can damage the soft metal or plastic parts of the connectors.
- Before working on internal components, make sure that the power is off. Ground yourself before touching any internal components, by touching a metal object. Static electricity can damage many of the electronic components. Humid environments tend to have less static electricity than

dry environments. A grounding strap is warranted whenever danger of static electricity exists.

Precautions

Computer components and electronic circuit boards can be damaged by discharges of static electricity. Working on computers that are still connected to a power supply can be extremely dangerous.

Follow the guidelines below to avoid damage to your computer or yourself:


- Always disconnect the unit from the power outlet whenever you are working inside the case.
- If possible, wear a grounded wrist strap when you are working inside the computer case. Alternatively, discharge any static electricity by touching the bare metal chassis of the unit case, or the bare metal body of any other grounded appliance.
- Hold electronic circuit boards by the edges only. Do not touch the components on the board unless it is necessary to do so. Don't flex or stress the circuit board.
- Leave all components inside the static-proof packaging that they shipped with until they are ready for installation.
- Use correct screws and do not over tighten screws.

Jumper Settings


A jumper is the simplest kind of electric switch. It consists of two metal pins and a cap. When setting the jumpers, ensure that the jumper caps are placed on the correct pins. When the jumper cap is placed on both pins, the jumper is short. If you remove the jumper cap, or place the jumper cap on just one pin, the jumper is open.

Refer to the illustrations below for examples of what the 2-pin and 3-pin jumpers look like when they are short (on) and open (off).

Two-Pin Jumpers: Open (Left) and Short (Right)




Three-Pin Jumpers: Pins 1 and 2 are Short



Locations of the Jumpers and Connectors for NISB 50

NISB 50

The figure below is the top view of the NISB 50 main board which is the main board used in Fanless Box-PC 50 / 50W. It shows the locations of the jumpers and connectors.



Jumpers

AT/ATX Power Select

Connector type: 1x3 3-pin header, 2.54mm pitch
Connector location: JP1



Pin	Settings
1-2 On	ATX Mode
2-3 On	AT Mode

1-2 On: default

Pin	Definition
1	3VSB
2	AT_ATX_SELECT
3	GND

CMOS Clear Select

Connector type: 1x3 3-pin header, 2.54mm pitch
Connector location: JP13



Pin	Settings
1-2 On	Normal
2-3 On	Clear CMOS

1-2 On: default

Pin	Definition
1	NC
2	RTC_TEST#
3	GND

ME Clear Select

Connector type: 1x3 3-pin header, 2.54mm pitch
Connector location: JP15



Pin	Settings
1-2 On	Normal
2-3 On	Clear ME

1-2 On: default

Pin	Definition
1	NC
2	SRTC_TEST#
3	GND

COM3 RS422/485 Select

Connector type: 1x3 3-pin header, 2.0mm pitch
Connector location: JP9



Pin	Settings
1-2 On	RS422
2-3 On	RS485

2-3 On: default

Pin	Definition
1	VCC5
2	RS485_OE
3	RS485_OE_RTS

SIM Card Power Select

Connector type: 1x3 3-pin header, 2.0mm pitch
Connector location: JP4



Pin	Settings
1-2 On	3G/mSATA (CN5)
2-3 On	3G/Wi-Fi (CN6)

1-2 On: default

Pin	Definition
1	UIM_PWR1
2	UIM_PWR
3	UIM_PWR2

COM1 5V/12V/RI Select

Connector type: 1x5 5-pin header, 2.0mm pitch
Connector location: JP11



Pin	Settings
1-2 On	+5V
2-3 On	+12V
4-5 On	Ring

4-5 On: default

Pin	Definition
1	VCC5
2	COM1_RI#_T
3	VCC12
4	COM1_RI#_T
5	COM1_RI#

COM3 TX Terminal Pin header

Connector type: 1x3 3-pin header, 2.0mm pitch
Connector location: JP6



Pin	Definition
1	TX+
2	TX-
3	GND



Note:
No need to have jumper on if it is 1.2M with CAT.6 cable based on testing. If have signal concern for long distance, please change the jumper on pin 1-2.

COM3 RX Terminal Pin header

Connector type: 1x3 3-pin header, 2.0mm pitch
Connector location: JP7



Pin	Definition
1	RX+_DATA+
2	RX-_DATA-
3	GND



Note:
No need to have jumper on if it is 1.2M with CAT.6 cable based on testing. If have signal concern for long distance, please change the jumper on pin 1-2.

Connector Pin Definitions

External I/O Interfaces - Front Panel

Power Button


Connector location: SW1



Pin	Definition	Pin	Definition
1	GND	2	EC_PWRBT#
3	EC_PWRBT#	4	GND
A1	PWR_SW_P	C1	PWR_SW_N
MH1	GND	MH2	GND

SIM Card Slot


Connector location: IDE1



Pin	Definition	Pin	Definition
C1	UIM_PWR	C2	UIM_RESET
C3	UIM_CLK	C5	GND
C6	UIM_VPP	C7	UIM_DATA

HDMI


Connector type: HDMI port
Connector location: CN8



Pin	Definition	Pin	Definition
1	HDMI_DATA2_P_C	2	GND
3	HDMI_DATA2_N_C	4	HDMI_DATA1_P_C
5	GND	6	HDMI_DATA1_N_C
7	HDMI_DATA0_P_C	8	GND
9	HDMI_DATA0_N_C	10	HDMI_CLK_P_C
11	GND	12	HDMI_CLK_N_C
13	HDMI_CEC	14	NC
15	HDMI_CTRL_CLK_C	16	HDMI_CTRL_DAT_C
17	GND	18	HDMI_PWR
19	HDMI_HPD_R		
MH1	CHASSIS_GND	MH2	GND
MH3	CHASSIS_GND	MH4	GND

USB1/2 Ports (USB 2.0)


Connector type: USB 3.0 port
Connector location: CN10



Pin	Definition	Pin	Definition
1	4USBV1	2	DN1_C
3	DP1_C	4	GND
5	4USBV1	6	DN2_C
7	DP2_C	8	GND
MH1	CHASSIS_GND	MH2	CHASSIS_GND
MH3	CHASSIS_GND	MH4	CHASSIS_GND

USB3/4 Ports (USB 2.0)


Connector type: USB 3.0 port
Connector location: CN9



Pin	Definition	Pin	Definition
1	4USBV2	2	DN3_C
3	DP3_C	4	GND
5	4USBV2	6	DN4_C
7	DP4_C	8	GND
MH1	CHASSIS_GND	MH2	CHASSIS_GND
MH3	CHASSIS_GND	MH4	CHASSIS_GND

LAN 1 Port

Connector type: RJ45 with LEDs
Connector location: LAN1




Pin	Definition	Pin	Definition
1	LAN_MDI0P_1	2	LAN_MDI0N_1
3	LAN_MDI1P_1	4	LAN_MDI1N_1
5	LAN1TCT	6	GND
7	LAN_MDI2P_1	8	LAN_MDI2N_1
9	LAN_MDI3P_1	10	LAN_MDI3N_1
11	LAN_LED_LINK1G#	12	LAN_LINK
13	LAN_LED_ACT#	14	LAN_ACTPW
MH1	CHASSIS_GND	MH2	CHASSIS_GND

LAN 2 Port

Connector type: RJ45 with LEDs

Connector location: LAN2




Pin	Definition	Pin	Definition
1	LAN2_MDI0P	2	LAN2_MDI0N
3	LAN2_MDI1P	4	LAN2_MDI1N
5	LAN2_TCT	6	GND
7	LAN2_MDI2P	8	LAN2_MDI2N
9	LAN2_MDI3P	10	LAN2_MDI3N
11	LAN2_LED_LINK1G#	12	LAN2_LINK
13	LAN2_LED_ACT#	14	LAN2_ACTPW
MH1	CHASSIS_GND	MH2	CHASSIS_GND

External I/O Interfaces - Rear Panel

24V DC Power Input

Connector location: CN11




Pin	Definition
1	VIN_1
2	VIN_VSS
3	R_GND

COM 1 Port (RS232)

Connector type: DB-9 port, 9-pin D-Sub


Connector location: COM3



Pin	Definition	Pin	Definition
1	COM1_DCD#_R	2	COM1_RXD_R
3	COM1_TXD_R	4	COM1_DTR#_R
5	GND	6	COM1_DSR#_R
7	COM1_RTS#_R	8	COM1_CTS#_R
9	COM1_RI#_T		
MH1	CHASIS_GNDR2	MH2	CHASIS_GNDR1

COM 2 Port (RS232)


Connector type: DB-9 port, 9-pin D-Sub
Connector location: COM2



Pin	Definition	Pin	Definition
1	N/A	2	SP2_RXD_R
3	SP2_TXD_R	4	N/A
5	GND	6	N/A
7	SP2_RTS#_R	8	SP2_CTS#_R
9	N/A		
MH1	CHASIS_GNDR3	MH2	CHASIS_GNDR2

COM 3 Port (RS422/485 Only)

Connector type: DB-9 port, 9-pin D-Sub
Connector location: CN3



RS485		RS422	
Pin	Definition	Pin	Definition
1	DATA-	1	TX-
2	DATA+	2	TX+
3	NC	3	RX+
4	NC	4	RX-
5	GND	5	GND
6	NC	6	RTS-
7	NC	7	RTS+
8	NC	8	CTS+
9	NC	9	CTS-
MH1	CHASIS_GNDR4	MH1	CHASIS_GNDR4
MH2	CHASIS_GNDR3	MH2	CHASIS_GNDR3
NH1	NA	NH1	NA
NH2	NA	NH2	NA

Line-out Connector

Connector type: 1x 3.5mm TRS
Connector location: CN1



Pin	Definition	Pin	Definition
1	LOUT_L3	2	LINE_OUT_JD
3	AGND	4	LOUT_R3
5	AGND	6	AGND

Internal Connectors

LAN1 LED Signal Pin Header

Connector type: 2x2 4-pin header, 2.0mm pitch
Connector location: JP12



Pin	Definition	Pin	Definition
1	LAN_ACTPW	2	LAN_LED_ACT#
3	LAN_LED_LINK1G#	4	LAN_LED_LINK#

LAN2 LED Signal Pin Header

Connector type: 2x2 4-pin header, 2.0mm pitch
Connector location: JP14



Pin	Definition	Pin	Definition
1	LAN2_ACTPW	2	LAN2_LED_ACT#
3	LAN2_LED_LINK1G#	4	LAN2_LED_LINK#

SATA Connector

Connector type: Standard Serial ATA 7P (1.27mm, SATA-M-180)
Connector location: CN2



Pin	Definition	Pin	Definition
1	GND	2	SATA_TXP0_C
3	SATA_TXN0_C	4	GND
5	SATA_RXN0_C	6	SATA_RXP0_C
7	GND		

SATA Power Connector


Connector type: 1x2 2-pin header, 2.0mm pitch
Connector location: J1



Pin	Definition
1	GND
2	VCC5

GPIO Pin Header

Connector type: 2x5 10-pin header, 2.0mm pitch
Connector location: JP2



Pin	Definition	Pin	Definition
1	VCC5	2	GND
3	ICH_GPO0_OUT	4	ICH_GPIO_IN
5	ICH_GPO1_OUT	6	ICH_GPI1_IN
7	ICH_GPO2_OUT	8	ICH_GPI2_IN
9	ICH_GPO3_OUT	10	ICH_GPI3_IN

Mic-in Pin Header

Connector type: 1x4 4-pin header, 2.0mm pitch
Connector location: JP5



Pin	Definition	Pin	Definition
1	MIC1_L3	2	AGND
3	MIC_JD	4	MIC1_R3

COM 4 Pin Header (RS232)


Connector type: 1x3 3-pin header, 2.0mm pitch
Connector location: COM1



Pin	Definition
1	GND
2	SP4_RXD_R
3	SP4_TXD_R

Power & HDD LEDs/Power & Reset Switches


Connector type: 2x6 12-pin header, 2.0mm pitch
Connector location: JP3



Pin	Definition	Pin	Definition
1	PWR_LED_N	2	VCC5
3	SATA_LED#	4	VCC5
5	3VSB	6	GND
7	SLP_S3#	8	PS_ON#
9	EC_PWRBT#	10	GND
11	PM_RESET#_J	12	GND

RTC Connector

Connector type: 1x2 2-pin header, 1.25mm pitch
Connector location: J3



Pin	Definition
1	GND
2	VBAT_L

SMBUS Pin Header


Connector type: 1x4 4-pin header, 2.0mm pitch
Connector location: JP8



Pin	Definition	Pin	Definition
1	VCC3	2	SMB_CLK
3	SMB_DATA	4	GND

SPI and I2C Pin Header


Connector type: 2x4 8-pin header, 1.27mm pitch
Connector location: JP10



Pin	Definition	Pin	Definition
1	3VSB	2	GND
3	3V3_SPI_CS	4	3V3_SPI_MISO
5	3V3_SPI_MOSI	6	3V3_SPI_CLK
7	3P3_I2C_CLK	8	3P3_I2C_DATA

GPIO Pin Header


Connector type: 2x5 10-pin header, 2.0mm pitch
Connector location: CN12



Pin	Definition	Pin	Definition
1	3VSB	2	GND
3	3V3_GPIO_IN1	4	3V3_GPIO_OUT1
5	3V3_GPIO_IN2	6	3V3_GPIO_OUT2
7	3V3_GPIO_IN3	8	3V3_GPIO_OUT3
9	3V3_GPIO_IN4	10	3V3_GPIO_OUT4

UART Pin Header (Signal from CPU)


Connector type: 2x3 6-pin header, 2.0mm pitch
Connector location: JP16



Pin	Definition	Pin	Definition
1	3VSB	2	GND
3	3V3_UART_RXD	4	3V3_UART_TXD
5	3V3_UART_RTS	6	3V3_UART_CTS

Mini-PCle Connector (3G/4G/mSATA)

Connector location: CN5




Pin	Definition	Pin	Definition
1	N/A	2	3VSB_MINI1
3	N/A	4	GND
5	N/A	6	V1P5S_1
7	N/A	8	UIM_PWR1
9	GND	10	UIM_DATA
11	N/A	12	UIM_CLK
13	N/A	14	UIM_RESET
15	GND	16	UIM_VPP
17	N/A	18	GND
19	N/A	20	MINICARD2DIS#
21	GND	22	N/A
23	SATA_RXP1_C	24	3VSB_MINI1
25	SATA_RXN1_C	26	GND

Pin	Definition	Pin	Definition
27	GND	28	V1P5S_1
29	GND	30	EC_SMBCLK
31	SATA_TXN1_C	32	EC_SMBDATA
33	SATA_TXP1_C	34	GND
35	GND	36	MINI1USBN
37	GND	38	MINI1USBP
39	3VSB_MINI1	40	GND
41	3VSB_MINI1	42	N/A
43	GND	44	N/A
45	N/A	46	N/A
47	N/A	48	V1P5S_1
49	N/A	50	GND
51	3VSB_MINI1	52	3VSB_MINI1

Mini-PCle Connector (3G/4G/Wi-Fi)

Connector location: CN6




Pin	Definition	Pin	Definition
1	PCIEWAKE#	2	3VSB_MINI2
3	N/A	4	GND
5	N/A	6	V1P5S_2
7	MINICARD2CLKREQ#	8	UIM_PWR2
9	GND	10	UIM_DATA
11	PCIE_CLKN0	12	UIM_CLK
13	PCIE_CLKP0	14	UIM_RESET
15	GND	16	UIM_VPP
17	N/A	18	GND
19	N/A	20	MINICARD2DIS#
21	GND	22	EC_PLTRST#
23	RXN0_R	24	3VSB_MINI2
25	RXP0_R	26	GND

Pin	Definition	Pin	Definition
27	GND	28	V1P5S_2
29	GND	30	EC_SMBCLK
31	TXN0_R	32	EC_SMBDATA
33	TXP0_R	34	GND
35	GND	36	MINI2USBN
37	GND	38	MINI2USBP
39	3VSB_MINI2	40	GND
41	3VSB_MINI2	42	N/A
43	GND	44	N/A
45	N/A	46	N/A
47	N/A	48	V1P5S_2
49	N/A	50	GND
51	N/A	52	3VSB_MINI2

Half-size Mini-PCle Connector (Wi-Fi)

Connector location: CN7



Pin	Definition	Pin	Definition
1	PCIE_WAKE#	2	3VSB_MINI3
3	N/A	4	GND
5	N/A	6	V1P5S_3
7	MINICARD1CLKREQ#	8	N/A
9	GND	10	N/A
11	PCIE_CLKN3	12	N/A
13	PCIE_CLKP3	14	N/A
15	GND	16	N/A
17	N/A	18	GND
19	N/A	20	MINICARD3DIS#
21	GND	22	EC_PLTRST#
23	RXN3_R	24	3VSB_MINI3
25	RXP3_R	26	GND

Pin	Definition	Pin	Definition
27	GND	28	V1P5S_3
29	GND	30	EC_SMBCLK
31	TXN3_R	32	EC_SMBDATA
33	TXP3_R	34	GND
35	GND	36	MINI3USBN
37	GND	38	MINI3USBP
39	3VSB_MINI3	40	GND
41	3VSB_MINI3	42	N/A
43	GND	44	N/A
45	N/A	46	N/A
47	N/A	48	V1P5S_3
49	N/A	50	GND
51	N/A	52	3VSB_MINI3

CHAPTER 3: SYSTEM SETUP

Removing the Chassis Cover



Prior to removing the chassis cover, make sure the unit's power is off and disconnected from the power sources to prevent electric shock or system damage.

1. Remove the six mounting screws around the chassis cover. There are two screws each on the top and on the sides.



2. With the screws removed, lift up the cover and remove it from the chassis.



Screws on the sides


Installing a Wi-Fi/BT Mini-PCle Module (Half-size)

1. Locate the mini-PCI Express slot (CN7) on the board.



2. Insert the Wi-Fi module into the mini-PCI Express slot at a 45 degree angle until the gold-plated connector on the edge of the module completely disappears inside the slot.

3. Push the module down and then secure it with mounting screws.



**Mounting
screw**


Installing a Mini-PCle Module (Full-size)

1. Locate the mini-PCI Express slot (CN5) on the board.



2. Insert the Wi-Fi module into the mini-PCI Express slot at a 45 degree angle until the gold-plated connector on the edge of the module completely disappears inside the slot.


3. Push the module down and then secure it with mounting screws.




Mounting
screw

Installing a 3G Mini-PCle Module (Half-size)

1. Align the 3G module to the module bracket and secure both together with screws.



2. Insert the wireless LAN module into the mini-PCI Express slot (CN6) at a 45 degree angle until the gold-plated connector on the edge of the module completely disappears inside the slot. Push the module down and then secure it with mounting screws.




Installing a SIM Card

1. Locate the SIM card slot on the front panel and remove the slot cover.



2. Insert the SIM card into the slot.



3. Insert the SIM card cover back to its original position.




SIM cover

Installing an Antenna



Note: Please remove the gaskets (ring 1 and ring 2) on the SMA antenna jack first.




1. Remove the antenna hole cover located on the front panel.



2. Insert the SMA antenna jack end of the cable through the antenna hole, and insert the 2 rings (ring 1 and ring 2) back to the antenna jack.



3. Attach the RF cable onto the module.



RF cable

4. Connect the external antenna to the antenna jack.



Installing a 2.5" SSD/HDD Storage (For Fanless Box-PC 50W Only)

1. Remove the HDD bracket located at the front panel by loosening the two thumb screws on the bracket cover.
2. Gently pull the HDD bracket out.



3. Prepare the mounting plate and its four screws. The mounting plate is used to secure the HDD to the bracket.

4. Secure the HDD onto the mounting plate with the four screws. Make sure the HDD connector is facing towards the cutout on the plate.



5. Place the HDD onto the HDD bracket with the connector facing towards the rear end of the bracket cover.



6. Insert the HDD bracket back into the external slot, then tighten the screws to secure it.



Note:
Please use a 2.5" SSD/HDD with a height no greater than 7mm.

Wallmount Installation

1. Align the M4 mounting holes on the chassis cover to the desired installation location.
2. Mount the system by fastening 4 screws through the mounting holes.



DIN Rail Clip Installation

1. Align the DIN rail clips to the mounting holes on the chassis cover.



2. Secure the DIN rail clips with screws.



Aluminum DIN Rail Clip Installation

1. Align the aluminum DIN rail clip to the mounting holes on the chassis cover.
2. Secure the aluminum DIN rail clip with screws.



Packing (Fanless Box-PC 50)




Fanless Box-PC 50 EPE reference.

Top View of Packing




Bottom View of Packing



Front View of Packing



Rear View of Packing




Packing (Fanless Box-PC 50W)




Fanless Box-PC 50W EPE reference.


Top View of Packing




Bottom View of Packing



Front View of Packing



Rear View of Packing



CHAPTER 4: BIOS SETUP

This chapter describes how to use the BIOS setup program for the Fanless Box-PC 50 / 50W. The BIOS screens provided in this chapter are for reference only and may change if the BIOS is updated in the future.

To check for the latest updates and revisions, visit the DELTA COMPONENTS web site at www.delta-components.de.

About BIOS Setup

The BIOS (Basic Input and Output System) Setup program is a menu driven utility that enables you to make changes to the system configuration and tailor your system to suit your individual work needs. It is a ROM-based configuration utility that displays the system's configuration status and provides you with a tool to set system parameters.

These parameters are stored in non-volatile battery-backed-up CMOS RAM that saves this information even when the power is turned off. When the system is turned back on, the system is configured with the values found in CMOS.

With easy-to-use pull down menus, you can configure such items as:

- Hard drives, diskette drives, and peripherals
- Video display type and display options
- Password protection from unauthorized use
- Power management features

The settings made in the setup program affect how the computer performs. It is important, therefore, first to try to understand all the setup options, and second, to make settings appropriate for the way you use the computer.

When to Configure the BIOS

- This program should be executed under the following conditions:
- When changing the system configuration
- When a configuration error is detected by the system and you are prompted to make changes to the setup program
- When resetting the system clock
- When redefining the communication ports to prevent any conflicts
- When making changes to the Power Management configuration
- When changing the password or making other changes to the security setup

Normally, CMOS setup is needed when the system hardware is not consistent with the information contained in the CMOS RAM, whenever the CMOS RAM has lost power, or the system features need to be changed.

Default Configuration


Most of the configuration settings are either predefined according to the Load Optimal Defaults settings which are stored in the BIOS or are automatically detected and configured without requiring any actions. There are a few settings that you may need to change depending on your system configuration.

Entering Setup












When the system is powered on, the BIOS will enter the Power-On Self Test (POST) routines. These routines perform various diagnostic checks; if an error is encountered, the error will be reported in one of two different ways:

- If the error occurs before the display device is initialized, a series of beeps will be transmitted.
- If the error occurs after the display device is initialized, the screen will display the error message.

Powering on the computer and immediately pressing allows you to enter Setup.

Press the  key to enter Setup:


Legends

Key	Function
	Moves the highlight left or right to select a menu.
	Moves the highlight up or down between sub-menus or fields.
	Exits the BIOS Setup Utility.
	Scrolls forward through the values or options of the highlighted field.
	Scrolls backward through the values or options of the highlighted field.
	Selects a field.
	Displays General Help.
	Load previous values.
	Load optimized default values.
	Saves and exits the Setup program.
	Press <Enter> to enter the highlighted sub-menu

Scroll Bar


When a scroll bar appears to the right of the setup screen, it indicates that there are more available fields not shown on the screen. Use the up and down arrow keys to scroll through all the available fields.

Submenu

When "►" appears on the left of a particular field, it indicates that a submenu which contains additional options are available for that field. To display the submenu, move the highlight to that field and press  .



BIOS Setup Utility

Once you enter the AMI BIOS Setup Utility, the Main Menu will appear on the screen. The main menu allows you to select from several setup functions and one exit. Use arrow keys to select among the items and press  to accept or enter the submenu.

Main

The Main menu is the first screen that you will see when you enter the BIOS Setup Utility.



System Date

The date format is <day>, <month>, <date>, <year>. Day displays a day, from Monday to Sunday. Month displays the month, from January to December. Date displays the date, from 1 to 31. Year displays the year, from 1999 to 2099.

System Time

The time format is <hour>, <minute>, <second>. The time is based on the 24-hour military-time clock. For example, 1 p.m. is 13:00:00. Hour displays hours from 00 to 23. Minute displays minutes from 00 to 59. Second displays seconds from 00 to 59.

Advanced

The Advanced menu allows you to configure your system for basic operation. Some entries are defaults required by the system board, while others, if enabled, will improve the performance of your system or let you set some features according to your preference.



Setting incorrect field values may cause the system to malfunction.



ACPI Settings

This section is used to configure ACPI Settings.



Enable Hibernation

Enables or disables system ability to hibernate (OS/S4 Sleep State). This option may not be effective with some OS.



ACPI Sleep State



Select the highest ACPI sleep state the system will enter when the suspend button is pressed. The options are Suspend Disabled and S3 (Suspend to RAM).

F81216SEC Super IO Configuration

This section is used to configure the serial ports of the F81216SEC Super IO.




Super IO Chip
Displays the Super I/O chip used on the board.



Serial Port 1 Configuration

This section is used to configure serial port 1.




Serial Port

Enables or disables the serial port.

IT8528 H/W Monitor

This section is used to monitor hardware status such as temperature, fan speed and voltages.



CPU Temperature (DTS)

Detects and displays the current CPU temperature.

System Temperature

Detects and displays the current system temperature.

VCore to VCC5

Detects and displays the output voltages.



Serial Port Console Redirection

This section is used to configure serial port console redirection settings.



Console Redirection

Enables or disables the console redirection. When enabled, Console Redirection Settings will be available.

Console Redirection (Serial Port for Out-of-Band Management)

Enables or disables the console redirection. When enabled, Console Redirection Settings will be available.

CPU Configuration

This section is used to configure the CPU.



Active Processors Cores

Select the number of cores to enable in each processor package.

Limit CPUID Maximum

The CPUID instruction of some newer CPUs will return a value greater than 3. The default is Disabled because this problem does not exist in the Windows series operating systems. If you are using an operating system other than Windows, this problem may occur. To avoid this problem, enable this field to limit the return value to 3 or lesser than 3.



Execute Disable Bit

When this field is set to Disabled, it will force the XD feature flag to always return to 0. XD can prevent certain classes of malicious buffer overflow attacks when combined with a supporting OS (Windows Server 2003 SP1, Windows XP SP2, SuSE Linux 9.2, RedHat Enterprise 3 Update 3).

Intel® Virtualization Technology

Enables or disables Intel Virtualization technology.

Socket 0 CPU Information

Display information on the CPU installed on socket 0.

Aptio Setup Utility - Copyright (C) 2013 American Megatrends, Inc.

Advanced

Socket 0 CPU Information

Intel(R) Atom(TM) CPU E3826 @ 1.46GHz

CPU Signature30679

Microcode Patch901

Max CPU Speed1460 MHz

Min CPU Speed533 MHz

Processor Cores2

Intel HT TechnologyNot Supported

Intel VT-x TechnologySupported

L1 Data Cache24 kB x 2

L1 Code Cache32 kB x 2

L2 Cache1024 kB x 1

L3 CacheNot Present

→←: Select Screen

↑↓: Select Item

Enter: Select

+/-: Change Opt.

F1: General Help

F2: Previous Values

F3: Optimized Defaults

F4: Save & Exit

ESC: Exit

Version 2.16.1242. Copyright (C) 2013 American Megatrends, Inc.

PPM Configuration

This section is used to configure the Processor Power Management (PPM) configuration.

Aptio Setup Utility - Copyright (C) 2013 American Megatrends, Inc.

Advanced

PPM Configuration

EIST[Disabled]

Enable/Disable Intel SpeedStep

→←: Select Screen

↑↓: Select Item

Enter: Select

+/-: Change Opt.

F1: General Help

F2: Previous Values

F3: Optimized Defaults

F4: Save & Exit

ESC: Exit

Version 2.16.1242. Copyright (C) 2013 American Megatrends, Inc.

EIST

Enables or disables Intel® SpeedStep.



IDE Configuration

This section is used to configure the SATA drives.



Serial-ATA (SATA)

Enables or disables the SATA controller.

SATA Mode

Configures the SATA as IDE or AHCI mode.

- IDE This option configures the Serial ATA drives as Parallel ATA physical storage device.
- AHCI This option configures the Serial ATA drives to use AHCI (Advanced Host Controller Interface). AHCI allows the storage driver to enable the advanced Serial ATA features which will increase storage performance.

Serial-ATA Port 0 and Serial-ATA Port 1

Enables or disables SATA port 0 or port 1.

SATA Port0 HotPlug and SATA Port1 HotPlug

Enables or disables hot pluggable support on SATA port 0 or port 1.



Miscellaneous Configuration

This section is used to configure other miscellaneous settings.



OS Selection

Selects the operating system as Windows or Android.

LPSS & SCC Configuration

This section is used to configure LPSS and SCC settings.



LPSS & SCC Devices Mode

Selects the LPSS and SCC device mode as ACPI mode or PCI mode.

SCC eMMC Support

Enables or disables SCC eMMC support.

SCC eMMC 4.5 DDR50 Support

Enables or disables SCC eMMC 4.5 DDR50 support.

SCC eMMC 4.5 HS200 Support

Enables or disables SCC eMMC 4.5 HS200 support.



CSM Configuration

This section is used to configure the compatibility support module features.



CSM Support

Enables or disables CSM support.

Network

Controls the execution of UEFI and legacy PXE OpROM.

Onboard LAN PXE

Enables or disables onboard LAN PXE ROM.

Storage

Controls the execution of UEFI and legacy storage OpROM.

Video

Controls the execution of UEFI and legacy video OpROM.

Other PCI Devices

Determines OpROM execution policy for devices other than network, storage or video.



USB Configuration

This section is used to configure the USB.

Aptio Setup Utility - Copyright (C) 2013 American Megatrends, Inc.

Advanced

USB Configuration

USB Module Version8.11.01

USB Devices:
1 Keyboard, 1 Mouse, 2 Hubs

Legacy USB Support[Enabled]

XHCI Legacy Support[Enabled]

XHCI Hand-off[Enabled]

EHCI Hand-off[Enabled]

USB Mass Storage Driver Support[Enabled]

USB hardware delays and time-outs:

USB transfer time-out[20 sec]

Device reset time-out[20 sec]

Device power-up delay[Auto]

Enables Legacy USB support. AUTO option disables legacy support if no USB devices are connected. DISABLE option will keep USB devices available only for EFI applications.

→←: Select Screen

↑↓: Select Item

Enter: Select

+/-: Change Opt.

F1: General Help

F2: Previous Values

F3: Optimized Defaults

F4: Save & Exit

ESC: Exit

Version 2.16.1242. Copyright (C) 2013 American Megatrends, Inc.

Legacy USB Support

- Enable Enables Legacy USB.
- Auto Disables support for Legacy when no USB devices are connected.
- Disable Keeps USB devices available only for EFI applications.

XHCI Legacy Support

Enables or disables XHCI controller legacy support.

XHCI Hand-off

This is a workaround for OSs that does not support XHCI hand-off. The XHCI ownership change should be claimed by the XHCI driver.

EHCI Hand-off

This is a workaround for OSs that does not support EHCI hand-off. The EHCI ownership change should be claimed by the EHCI driver.

USB Mass Storage Driver Support

Enables or disables USB mass storage driver support.

USB Transfer Time-out

The time-out value for control, bulk, and Interrupt transfers.

Device Reset Time-out

Selects the USB mass storage device’s start unit command timeout.

Device Power-up Delay

Maximum time the value will take before it properly reports it self to the Host Controller. “Auto” uses default value: for a Root port it is 100 ms, for a Hub port the delay is taken from Hub descriptor.

62



Trusted Computing

This section is used to configure Trusted Platform Module (TPM) settings.

Aptio Setup Utility - Copyright (C) 2013 American Megatrends, Inc.

Advanced

Configuration

Security Device Support

[Disabled]

Current Status Information

NO Security Device Found

Enables or Disables BIOS support for security device. O.S will not show Security Device. TCG EFI protocol and INT1A interface will not be available.

→←: Select Screen

↑↓: Select Item

Enter: Select

+/-: Change Opt.

F1: General Help

F2: Previous Values

F3: Optimized Defaults

F4: Save & Exit

ESC: Exit

Version 2.16.1242. Copyright (C) 2013 American Megatrends, Inc.

Security Device Support

Enables or disables BIOS support for security device. O.S will not show Security Device. TCG EFI protocol and INT1A interface will not be available.



Chipset

This section gives you functions to configure the system based on the specific features of the chipset. The chipset manages bus speeds and access to system memory resources.



South Bridge

Enters the South Bridge submenu.

South Bridge



High Precision Timer

Enables or disables high precision event timer.

Restore AC Power Loss

Select the AC power state when power is re-applied after a power failure.



PCH Azalia Configuration

Aptio Setup Utility - Copyright (C) 2013 American Megatrends, Inc.

Chipset

Audio Configuration

Audio Controller

Azalia HDMI Codec

[Enabled]
[Enabled]

Control Detection of the Azalia device.
Disabled = Azalia will be unconditionally disabled
Enabled = Azalia will be unconditionally Enabled
Auto = Azalia will be enabled if present, disabled otherwise.

→←: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
ESC: Exit

Version 2.16.1242. Copyright (C) 2013 American Megatrends, Inc.

Azalia

Control detection of the Azalia device.

- Disabled
- Azalia will be unconditionally disabled.
- Enabled
- Azalia will be unconditionally enabled.

Azalia HDMI Codec

Enables or disables internal HDMI codec for Azalia.

USB Configuration

Aptio Setup Utility - Copyright (C) 2013 American Megatrends, Inc.

Chipset

USB Configuration

XHCI Mode

USB 2.0(EHCI) Support

USB RMH Mode

USB EHCI debug

[Disabled]
[Enabled]
[Enabled]
[Disabled]

Control the USB EHCI (USB 2.0) functions. One EHCI controller must always be enabled.

→←: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
ESC: Exit

Version 2.16.1242. Copyright (C) 2013 American Megatrends, Inc.

USB 2.0(EHCI) Support

Enables or disables the Enhanced Host Controller Interface (USB 2.0), one EHCI controller must always be enabled.

USB RMH Mode

Enables or disables PCH USB rate matching hubs mode.

USB EHCI Debug

Enables or disables PCH EHCI debug capability.



PCI Express Configuration

Aptio Setup Utility - Copyright (C) 2013 American Megatrends, Inc.

Chipset

PCI Express Configuration

PCI Express Port 0

[Enabled]

PCI Express Port 1

[Enabled]

PCI Express Port 2

[Enabled]

PCI Express Port 3

[Enabled]

Enable or Disable the PCI Express Port 0 in the Chipset.

-----: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
ESC: Exit

Version 2.16.1242. Copyright (C) 2013 American Megatrends, Inc.

PCI Express Port 0 to PCI Express Port 3

Enables or disables the PCI Express ports 0 to 3 on the chipset.

Security

Aptio Setup Utility - Copyright (C) 2013 American Megatrends, Inc.

MainAdvancedChipsetSecurityBootSave & Exit

Password Description

If ONLY the Administrator's password is set, then this only limits access to Setup and is only asked for when entering Setup.
If ONLY the User's password is set, then this is a power on password and must be entered to boot or enter Setup. In Setup the User will have Administrator rights.
The password length must be in the following range:
Minimum length3
Maximum length20

Administrator Password
User Password

Set Administrator Password

-----: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
ESC: Exit

Version 2.16.1242. Copyright (C) 2013 American Megatrends, Inc.

Administrator Password

Select this to reconfigure the administrator's password.

User Password

Select this to reconfigure the user's password.



Boot

This section is used to configure the boot features.



Bootup NumLock State

This allows you to determine the default state of the numeric keypad. By default, the system boots up with NumLock on wherein the function of the numeric keypad is the number keys. When set to Off, the function of the numeric keypad is the arrow keys.

Fast Boot

When enabled, the BIOS will shorten or skip some check items during POST. This will decrease the time needed to boot the system.

Boot Option Priorities


Adjust the boot sequence of the system. Boot Option #1 is the first boot device that the system will boot from, next will be #2 and so forth.

Hard Drive BBS Priorities

Sets the order of the legacy devices in this group.



Hard Drive BBS Priorities
Boot Option #1



Sets the first legacy device to boot from.

Save & Exit



Save Changes and Reset

To save the changes and reset, select this field then press <Enter>. A dialog box will appear. Confirm by selecting Yes.

Discard Changes and Reset

To exit the Setup utility without saving the changes, select this field then press <Enter>. You may be prompted to confirm again before exiting.

Restore Defaults

To restore the BIOS to default settings, select this field then press <Enter>. A dialog box will appear. Confirm by selecting Yes.

APPENDIX A: POWER CONSUMPTION

Power Consumption Management

Purpose

The purpose of the power consumption test is to verify the power dissipation of system, and the loading of power supply.

Test Equipment

1. 19" LCD Monitor.
2. DC power supply.
3. Operating System OS: Windows 8.1 (32-bit)
4. Burn In Test Ver7.1
5. Intel® Thermal Analysis Tool software version: 5.0.1019
6. Direct3D Play Test Program
7. Network test program.
8. USB 2.0 (5V, 0.5A (Cement Resistor)) *4.

Device Under Test

DUT: SYS#1

Test Procedure

1. Make sure mechanical structure and electrical functionality are normal before testing.
2. Install all I/O load devices and according as system input voltage specifications to setup DC power supply voltage.
3. Measure system maximum power consumption as below mode:
 - Standby mode.
 - BIOS mode.
 - 100% Full loading mode (include USB load fixture)
4. Measure and record system maximum power consumption value.

Test Result

System Mode		24Vdc	
		I _{max} .	W _{max} .
CPU: Intel® Atom™ CPU E3826 @ 1.46 GHz System model: PKBX5452 / Revision: B BIOS: American Megatrends Inc. / Revision: N050B013 X64 EC Revision: C 00 2 Operating System OS: Windows 8.1 (32-bit)	Standby mode. (S3)	0.10A	2.4W
	BIOS mode	0.36A	8.64W
	100% Full loading mode.	0.8A	19.2W

APPENDIX B: GPIO CONTROL COMMANDS

This command set is used to control GPIO. The system retrieves a HW pin number from the dynamic control table and sends it to EC. The EC will then use this code to control the real pin. Read/write/set direction/set internal pull up/down GPIO functions are available to the system. Only GPIO-type device id in the dynamic control table can be a controller, the EC does not allow the system to control other pins not defined in the table.

Command List

Command	Description						
0x10	Write Pin number into index						
0x11	According index, get GPIO pin status. 1-active, 0-unactive, 0xFF-fail						
0x12	According index, change GPIO pin status. 1-active, 0-unactive						
0x1D	According index, get GPIO input/output type. 1-output, 0-input, 0xFF-fail						
	Bit7 & Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
	0x10 Input	x	x	x	0x10Pull-up		x
	0x01 Output	x	x	x	0x01Pull-dn		x
0x1E	According index, change GPIO input/output type. 1-output, 0-input						
	Bit7 & Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
	0x10 Input	x	x	x	0x10Pull-up		x
	0x01 Output	x	x	x	0x01Pull-dn		x

GPIO Default Table

There are 8 alternate GPIOs in the COM specification. The system can use commands to control these pins. The system can also setup a default table to configure these GPIO behaviors when power resumes for the first time. This table can be stored into the EEPROM for first time use. The addresses in the ACPI RAM are as follows:

Default Table in ACPI RAM

GPIO0 start address: 0xD8	GPIO4 start address: 0xE4
GPIO1 start address: 0xDB	GPIO5 start address: 0xE7
GPIO2 start address: 0xDE	GPIO6 start address: 0xEA
GPIO3 start address: 0xE1	GPIO7 start address: 0xED

Offset	Name	Description																
0x00	Pin	HW pin number. EC will setup this value.																
0x01	Type control	Value type is same as command 0x1D.																
0x02	Default control	Setup default pin behavior																
		<table><tr><td>Bit7</td><td>Bit6</td><td>Bit5</td><td>Bit4</td><td>Bit3</td><td>Bit2</td><td>Bit1</td><td>Bit0</td></tr><tr><td>x</td><td>x</td><td>x</td><td>x</td><td>x</td><td>x</td><td>x</td><td>HiLow</td></tr></table>	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0	x	x	x	x	x	x	x	HiLow
		Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0									
		x	x	x	x	x	x	x	HiLow									
HiLow – If type control is input type, 1-high active and 0-low active.																		
If type control is output type, 1-default output high and 0-default output low.																		

Read GPIO Status Sequence

Step	Action	Description
0	Wait IBF clear	
1	Write 0x10 to 0x66	Send GPIO index command
2	Wait IBF clear	
3	Write PIN number to 0x62	Write pin number to index
4	Wait OBF set	
5	Read 0x62 port	If index setup successfully, EC will return pin number. If fail, EC will return 0xFF
6	Wait IBF clear	
7	Write 0x11 to 0x66	Send read GPIO status command
8	Wait OBF set	
9	Read 0x62 port	EC will return pin status according pin number which you set in index. 1-GPIO is high. 0-GPIO is low. 0xFF-fail.

Write GPIO Status Sequence

Step	Action	Description
0	Wait IBF clear	
1	Write 0x10 to 0x66	Send GPIO index command
2	Wait IBF clear	
3	Write PIN number to 0x62	Write pin number to index
4	Wait OBF set	
5	Read 0x62port	If index setup successfully, EC will return pin number. If fail, EC will return 0xFF
6	Wait IBF clear	
7	Write 0x12 to 0x66	Send write GPIO status command
8	Wait IBF clear	
9	Write pin status to 0x62 port	Write 0x01, GPIO pin will be set high. Write 0x00, GPIO pin will be set low.

Read GPIO Direction Sequence

Step	Action	Description
0	Wait IBF clear	
1	Write 0x10 to 0x66	Send GPIO index command
2	Wait IBF clear	
3	Write PIN number to 0x62	Write pin number to index
4	Wait OBF set	
5	Read 0x62 port	If index setup successfully, EC will return pin number. If fail, EC will return 0xFF
6	Wait IBF clear	
7	Write 0x1D to 0x66	Send read GPIO direction command
8	Wait OBF set	
9	Read 0x62 port	EC will return pin status according pin number which you set in index. 0x80-input, 0x40-output. 0xFF-fail

Write GPIO Direction Sequence

Step	Action	Description
0	Wait IBF clear	
1	Write 0x10 to 0x66	Send GPIO index command
2	Wait IBF clear	
3	Write PIN number to 0x62	Write pin number to index
4	Wait OBF set	
5	Read 0x62 port	If index setup successfully, EC will return pin number. If fail, EC will return 0xFF
6	Wait IBF clear	
7	Write 0x1E to 0x66	Send write GPIO direction command
8	Wait IBF clear	
9	Write pin status to 0x62 port	Write 0x40, GPIO pin will be set output. Write 0x80, GPIO pin will be set input.